

# **KERASAFE+**

**WORKING INSTRUCTIONS** 









#### **WALLS**



1. Before you start, cut the required number of KerSafe + foils ready for the job. If you need more open time for the foil installation, prime the substrate. Mix liquid A and powder X components of the adhesive carefully. The pot life of a mixed product is min. 1 h and coverage approx. 12 m<sup>2</sup>.



**2.** Lay Kiilto KeraSafe+ foils one by one with Kiilto KeraSafe Speed A+X adhesive.



**3.** Lay every foil at least 5 cm over the previous one. The lower edge of the foils must stretch 5 cm on the floor.




**4.** Press the foil tightly onto the substrate and rub into position with a rigid plastic trowel so that all air is pressed out and the foil is 100 % adhered to the substrate.



**5.** Inlets need not to be measured accurately, since they will be covered with a prefabricated reinforcement piece with KeraSafe Speed A+X adhesive.



**6.** Lay the next foil and carefully rub onto the substrate. The adhesive oozing out of the seams can be levelled out on the foil surface.



**7.** As the last foil is installed, you can start tiling. Start the tiling from the same wall as you started laying the KeraSafe + foils.

### WHY CHOOSE KERASAFE+?

- 1. Finished waterproofing in one single operation
- 2. Always correct membrane thickness
- 3. Quick and easy to install



#### **FLOORS**



1. Install Kiilto KeraSafe Kaivolaippa reinforcement on the floor drain before laying KeraSafe+ foils.



**2.** Start laying KeraSafe + foils on the floor in the same manner as on the walls: one by one with min. 5 cm overlaps.



**3.** Corner reinforcements are fixed with KeraSafe Speed A+X adhesive.



**4.** Wait at least 2 hours after the foil installation before cutting a hole for the floor drain and starting tiling.



## KIILTO PRO

SAVE DAYS - EVEN WEEKS
WITH RAPID SYSTEM PRODUCTS!

#### **CONSTRUCTION OF THE SYSTEM**





KIILTO OY • PO BOX 250, 33101 TAMPERE • Tel. +358 (0)207 710 100